

Book Stand instructions



Instructions

Turn the book stand around to look at the back. Lift the translucent plastic tab on the left side up and adjust the angle of the stand to suit you. Push the translucent plastic tab back down to lock the angle in place.

Set the bookstand down on a surface.

Try to keep it at your eye level for comfortable viewing.

Adjust the page holders to keep your item steady.

Read!