



Tonie Boxes instructions

Charging

Plug the included charger into a power outlet. Place the charger somewhere flat and secure. Put the Toniebox onto the barrel of the charger. The Toniebox and charger should magnetically snap together. An LED light will glow green when the battery is sufficiently charged. The LED lights up orange when the battery is low.

How to turn this Toniebox on

Pinch one of the ears with a thumb and forefinger. Or, you can place the box on its charging station.

Playing and pausing

When the light on the Toniebox turns green, place a Tonie figure on top. Want to pause the story or song? Just remove the Tonie figure from the Toniebox. When you place your Tonie back on, it will pick up from the same spot as long as another Tonie hasn't played in between.

Change the volume

Pinch the big ear to turn the volume of the Toniebox up. Pinch the little ear to turn it down.

Skip back and forth

To skip back and forth between chapters or songs, hold the Toniebox with one hand and tap on its side with the other. To fast-forward or rewind, tilt the box to one side.

Bedtime stories

If a Toniebox finishes a bedtime story, it turns off.

Does it have to be online?

No, content is loaded on the Tonie figurines.